



## HT8-1.2 CIRCUIT DIAGRAM



## FITTING A REPLACEMENT SWITCH

### INSTRUCTION FOR NORTH AMERICA



### INSTRUCTION FOR EEC, AUS, NZ

