

Setting UFO Counterweights

The UFO counterweights need to be set opposite the bearing or the UFO will vibrate. See photos.

